



WARNING & CARE INFORMATIONS

all models

www.gesslein.de





THANK YOU!

By purchasing Smiloo, you have chosen a quality Pram, that will help you to make being underway with your child a comfortable and active experience.

Thank you for placing your confidence in us. We hope you enjoy your new Pram

Our products accompany your baby from day one, let your family start off each day in a new and exciting way. They also grow with your child and their needs.

At GESSLEIN, we place great value on customer satisfaction and especially on the well-being of your little ones.

Our Pram features a modern design, innovative technology and are made from only the best materials.

All our fabrics are tested for harmful substances and are intricately hand sewn.

Our prams are manufactured according to the strict safety requirements of the EN 1888:2012 / EN 1466:2012 standard and guarantee safe and comfortable transport of your child.





Please read these instructions carefully before using the Smiloo for the first time.

Important – Keep these instructions for future reference

Not following these instructions, can put your child's safety at serious risk.

Never leave the child unattended

Please remove and discard any plastic bags, tags and packaging immediately to avoid risk of choking to infants and young children.

Ensure that all the locking devices are engaged before use

To avoid injury ensure that the child is kept away when unfolding and folding this product.

Do not let the child play with this product

Use a harness as soon as the child can sit unaided.

This seat unit is not suitable for children under 6 months

If you intend to use the seat unit for smaller children, please use a special harness system approved for newborn babies.

Always use the fully reclined position for newborn babies.

Always use the restraint system

RISK OF STRANGULATION: Never leave your child unattended in the pram/in the baby car seat when the harness is loose or open. Your child could be strangled by it. Also, make sure that no objects with ribbons or strings (e.g. caps, soothers, mobiles) are within your child's reach.

Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use

This product is not suitable for running or skating

WARNING FOR CARRYCOT AND CARRIER

This product is suitable for a child who cannot sit up unaided, roll over and cannot push itself up on its hands and knees. Maximum weight of the child: 9 kg

Place the carrycot or carrier on a firm, level and dry surface only.

Do not let other children play unattended near the carrier or carrycot.

Do not use the carrycot or carrier if parts are broken, torn or missing.

Do not leave flexible carrying handles inside the prambody





IMPORTANT SAFETY INSTRUCTIONS

ATTENTION! – General information

The safety of your child is your responsibility.

Check that your Smiloo is in proper condition before each use.

Please do not use it if any part is broken, torn or missing.

To ensure your child's safety, all damaged or worn parts should be repaired immediately before using the pram again.

We offer a number of spare parts and accessories for the Smiloo.

Please use exclusively these original parts or products which GESSLEIN has expressly approved for use with Smiloo.

Safety risks cannot be excluded for use of products not explicitly approved.

Smiloo is intended for solely one child – never transport more than one child at the same time in or with the pram.

When parking the stroller, always use the brake and check that it is securely locked.

Please ensure that the brake is always engaged when you take your child out of or put it into the pram.

Avoid parking the pram on a slope as much as possible.

Pay particular attention that the pram is secured when using public transport

When climbing stairs with the Smiloo, please roll the pram slowly and gently over the steps.

Please do not use the pram on escalators.

Never place anything on top of the canopy.

When carrying the pram over obstacles (e.g. stairs), please ensure that none of the lock devices become disengaged

Please ensure that your child is not within reach of moving parts when adjusting the individual positions

Heavy loads, improper folding or the use of non-approved accessories can damage your Smiloo.

Child seats used in conjunction with a chassis, replace neither a cradle nor a cot. If your child needs sleep, it should be placed in a suitable carrycot, a suitable cradle or a suitable bed.

When putting your child to sleep, put it in a suitable carrycot, a suitable cradle or a crib

ATTENTION! – Recommended weights and sizes

Smiloo can be used in combination with the carrycot, carrier or Group 0 harness from birth up to the age of 36 months.

The maximum weight of a child for the carrycot and carrier is 9 kg (20 lbs).

The seat unit is suitable for infants and toddlers 6 to 36 months (20 kg / 44 lbs) and up to a height of 102 cm (40 in).

The maximum weight for the frame basket is 4 kg (8.8 lbs).

Exceeding the manufacturer's recommended load weight will no longer guarantee the stability of the pram.

All loads on the handlebar and/or on the back of the backrest and/or attached to the sides of the pram affect its stability.

ATTENTION! – Information on using the transporting attachments (carrycot or carrier)

Please pay attention to the risks posed by open fires and other sources of heat sources such as electric heaters, gas flames, etc. if they are in close proximity to the carrycot or carrier.

Be sure to use the mattress underlay supplied by GESSLEIN and no other product.

Check the handles and the bottom regularly for damage or wear and tear

Make sure the handle on the carrycot is always in the correct (=vertical) position of use when carrying or lifting the product.

Never place the carrycot or carrying case on a stand.





CARE / MAINTENANCE

Your pram will be subjected to heavy stress and also become soiled when used daily on dusty, muddy or snowy roads and paths.

Care and maintenance of a high-quality Pram such as the Smiloo is particularly important so that the individual parts always function properly.

By following the care tips and instructions below, you will have long enjoyment from your Smiloo!

General information

Never expose your Smiloo to prolonged direct sunlight out.

As all types of fabric fade to a certain extent, the original colour of the textiles could change.

Always use the rain cover in case of rain or snow.

To prevent mould from growing, never store the pram in a damp spot.

Make sure that the pram is always completely dry after use and before storage.

Should your pram come into contact with salt (e.g. at sea or gritted walkways), please rinse off the chassis and dry it carefully afterwards.

Please ensure that the sensitive surface of your Smiloo does not become damaged during transport or storage.

Scratches which occur after the purchase do not constitute a reason for a complaint.

Care and maintenance of the wheels

Please remove the wheels regularly and clean them with a brush and water.

Lubricate the bearings and axles with a suitable lubricant afterwards.

Treat the caps on the front wheels as well as any metal parts after cleaning and before winter with an anti-corrosion agent.

To avoid squeaking, also lubricate the small springs on the front and rear axle regularly.

Care and maintenance of the chassis

Clean the mechanical parts of the chassis with a soft brush. When removing dirt, always brush in the direction away from the hinge joints.

Simply wipe the handlebar with a damp cloth.

Please check regularly that all screws and rivets are tight and intact.

Lubricate all joints and axles regularly with a suitable lubricant.

Check all parts subject to wear and tear periodically and replace them if necessary.

Treat all rivet or screw heads as well as all metal parts after cleaning and before winter with an anti-corrosion agent.

Care of fabric parts

You can remove the seat cover and the canopy on the Smiloo and wash them in the washing machine.

Unscrew the canopy bracket and remove it from the support rods before washing.

When washing the fabric parts of the pram, please wash at a maximum temperature of 30 °C / 85 °F (cold wash) and use a mild detergent only.

Do not bleach the fabric, use the spin cycle, iron or dry clean.

Always wash the fabric parts on the pram separately.

Do not place the wet or damp fabric parts in direct sunlight.

It is best to dry the fabric parts whilst hung out in an airy and dry room.





GUARANTEE

As a manufacturer – GESSLEIN GmbH – based in Redwitz (hereinafter referred to as "GESSLEIN"), we provide (hereinafter referred to as "Product") a guarantee on Smiloo under the following conditions:

The warranty period is 12 months from the date of purchase.

This warranty is valid worldwide except in the United States and Canada.

The warranty guarantees repairs but expressly does not guarantee exchange or the right to return the product.

GESSLEIN bears the transport costs and risk of transportation from and to the specialist dealer where the product was purchased (hereinafter referred to as "the Dealer"), provided the repair is covered by the warranty.

Claims can only be made under the warranty when GESSLEIN has received the defective product as well as the following:

- a copy of the sales receipt with purchase date including
- a clear description of the complaints.

The warranty is not transferable and can only be claimed by the original owner.

The warranty does not affect any possible rights entitled to you such as the right to hold the retailer liable for defects.

The following are not covered by the warranty:

Changes or repairs that you have made yourself or have had performed without having previously obtained written authorisation from GESSLEIN or the dealer.

Damage caused by negligence or by an accident and/or by other use or service than those specified in the user manual.

Products with a damaged or removed serial number

Damages to the product resulting from normal wear and tear

Drawn threads provided they clearly involve woven fabrics

Roughened surfaces or abrasion to stressed parts (for example in the foot area)

Formation of bobbles (removal such as with wool jumpers using a clothes brush or bobble remover)

Water stains due to cleaning or rainy weather

Bleeding of colour from washing

Fading of fabric due to sunlight exposure

Colour differences between individual production batches

(accessories should always be ordered with the pram)

Parts subject to wear and tear such as wheels, joints, connectors loose rivets and screw connectors

Noise due to lack of lubrication

Any damages based on disregard for the care and maintenance instructions

Rust formation due to lack of corrosion protection

Important information

The warranty period is 12 months from the date of purchase.

Should any damage occur, please first contact your dealer.

If the dealer is unable to repair the damage you can feel free to contact GESSLEIN.

Retain the user manual and your sales receipt in a safe place.

To avoid costly repairs, we strongly advise you to have the pram serviced after 6 months of use.

For information, please visit www.gesslein.de.

The Pram Smiloo is a premium model to which we attach great importance to exclusive materials and excellent craftsmanship, to ensure you and your child maximum comfort and safety.

For this reason, only original accessory parts and accessories or products which have been specifically authorised by us for Smiloo may be used with Smiloo.

Should you need a replacement part, please contact your dealer or order it directly from www.gesslein.de.

You can send us your queries, suggestions and comments at any time to service@gesslein.de

Visit our website at www.gesslein.de to receive current information on Smiloo and our other products.







FOLLOW US   
www.gesslein.de

Gesslein GmbH · Redwitzer Straße 33 · 96257 Redwitz · Tel.: 0 92 64 / 99 51 - 0 · Fax: 0 92 64 / 99 51 - 51 · E-Mail: info@gesslein.de

