



Legend

For illustrations see page 2

- a. Handlebar
- b. Upper lock
- c. Rear hood cover
- d. 5-point-safety harness
- e. Back rast adapter
- f. Net basket
- g. Parking brake
- h. Rear wheel
- i. Hood
- j. Harness pats
- k. Bumper bar
- l. Foot rest
- m. Swivel wheel lock
- n. Front wheel hanging
- o. Front wheel

Lieferumfang

Abbildung auf Seite 3

- (1) Chassis
- (2) Front wheels
- (3) Rear wheels
- (4) Bumper bar
- (5) Hood

Assemble your s1

The illustration to the numbers see on pages 3-5.

The left and right sides areas seen from the handlebar/back of the s1.

Attaching the rear wheels

(6) List the chassis on a flat surface with the rear of the backrest facing upwards. sure that the hooked clip in the centre of the axle is pointing downwards and towards the chassis. Click each wheel into place.

(7) Press the clip on the axle onto the hook on the back of the chassis until it clicks into place. Pull gently on each wheel to make sure it is secure.

Removing the front wheels

(9) Push the button on each of the front wheel joints and pull the wheel loose.

Unfolding the s1

(10) Lift the pushchair holding the handlebars as you would to push it. On each handlebar is a circular release clip. Pull both upwards. This will release the folding clip.

(11) Place your foot firmly on the small ledge on the backrest and push whilst pulling the handlebars towards you to fully open the chassis.

(12) Click the bottom end of each frame into place above the front wheel joint.

WARNUNG! Make sure that the bottom end of each handlebar is clicked firmly in place before using the pushchair

Attaching the bumper bar

(13) Insert the ends of the bumper bar into the slots at the end of each armrest with the release button facing downwards.

If the ends don't click into place, you may be inserting the bumper bar upside down. Check the bumper bar is securely in place by pulling on it.

(14) To remove, push in the release buttons underneath the armrests on each side and pull the bumper bar away from the arm.

Attaching the Hood

(15) Slide the clasps, located at the base of the hood frame, into the slots directly above the armrests on both sides of the pushchair.

(16) Push them into place until you hear a click pull gently on the frame of the hood to ensure it is secure. Secure the fabric ends of the hood underneath the arms of the push chair using the velcro patches.

Fitting the harness

Put on the buggy parking brake and make sure that the safety harness is unfastened before you place the child in the seat.

(17) Push the catches into one another and secure the strap between the legs to the lap belt and shoulder straps by clicking the catches into the belt lock.

Depending on the child's size, adjust the belts by shortening or lengthening them using the buckles (A).

(18) To undo the harness press the fastener prongs and pull apart.

(19) The shoulder belt can be attached at three different heights in order to adjust the harness better to the size of your child.

Function for using

Operating the brake

(20) Push down firmly on either of the brake levers above the rear wheels to engage the brake. Check the brake is on by gently pushing the pushchair.

To release the brake, lift either of the brake levers up the safety harness is unfastened before you place the

Locking the front wheel

It is recommended that the front wheels are locked when travelling on uneven surfaces to prevent the pushchair from shaking.

(21) To lock the wheels push the clips on each of the front wheel joints downwards until a click is heard. To unlock, lift the clips upwards.

Adjusting the backrest

(22) Behind the backrest, between the handlebars, is a release lever. Lift the lever fully upwards to release the seat and gently push or pull into the required position. There are four different positions from upright to fully reclined.

Once you have positioned the backrest, let go of the lever. Gently push the backrest down to ensure it has clicked into the nearest position.

Rotating the handles

The handles can be rotated for your comfort.

(23) Situated below the circular release clip, on each handlebar, is a sliding collar. Slide downwards and rotate the handle to the desired position.

Release the collar to secure in place.

Folding stroller

Folding the travel system.

Remove your child, and the car seat if attached. Apply the brake, fully recline the seat and push the hood back. Finally, ensure that the shopping basket is empty and front wheels are unlocked.

(24) Pull the circular release clips on the handle bars upwards to enable you to begin folding the pushchair.

(25) Place one hand on the handle at the back of the backrest and the other on a handle bar.

(26) Pull the backrest handle whilst pushing the handle bar. The pushchair will begin to fold.

(27) When the pushchair is partially folded, push down gently on the armrests to ensure it is fully folded.

(28) Check the folding latch has clipped into place.

(29) When the folding latch is in place, you can carry the folded pushchair using the handle on the side.

(30) Chassis stand after folding